


Fobis Technologies Inc.

"designing gadgets for real life"



READ ME FIRST!

weemote® 2 **QUICKSTART** **GUIDE**

© 2/01, Property of Fobis Technologies Inc.
Rev. 6/0301

patent pending
weemote® is a registered trademark

INTRODUCTION

This installation guide is designed to get your weemote® 2 setup as quickly as possible. **In order to ensure a fast setup, please follow this guide, step-by-step, in the order presented.** Doing so will save you from possible confusion and frustration later.

The companion "REFERENCE GUIDE" provides more detail for those who need more information, have complex entertainment systems or wish to further customize the Weemote's setup. It also contains the TV and Set-Top codes needed to configure your Weemote®.

You will need to refer to Reference Guide to find your TV, TV/VCR and Set-Top codes. Just follow the steps in this guide and we will instruct you whenever the Reference Guide is needed.

We welcome your feedback on our manual. If you have any suggestions, please email us at info@fobis.com.

If you run into any difficulty, please visit our web site at www.weemote.com for the latest updates and technical bulletins.

We also encourage you to register your weemote® so we can inform you of other cool gadgets we are working on. You can register online at our web site or fill out and mail the enclosed post card.

Enjoy your weemote® 2!

The Fobis Team

Need help? Go to www.weemote.com

STEP 1

BEFORE YOU BEGIN

1. If you have a cable-ready TV or TV/VCR.
COMPLETE Steps 1-9 in this guide

Please note that the weemote® is already loaded with the most popular Sony TV code.

2. If you have a cable-ready TV connected to a Set-Top box.

COMPLETE Steps 1-13 in this guide

Set-Top boxes are defined as cable TV boxes and satellite receivers such as DirecTV and Echostar. *Please note that we consider TiVo or Replay players as a Set-Top device in the weemote®.*

3. If you only want to program your Set-Top box.

COMPLETE Steps 1-5 and 10-13 in this guide

Please note that if you only want all weemote® controls to be sent to the Set-Top box, you must clear the TV code already set in your weemote®. Please refer to the reference guide on how to clear the TV code.

NOTE: The weemote® 2 will not work if you are using a separate VCR's tuner as your method for changing channels on your TV. The weemote® will also not work with UHF (radio) based remote control systems sometimes used in satellite receivers like Echostar.

Need help? Go to www.weemote.com 3

STEP 2

WHAT YOU NEED

1. The weemote®
2. This Guide
3. Reference Guide
4. Battery Sticker
(one battery sticker is already mounted inside the battery cover)
5. *A small philips head screw-driver
6. *2 AAA Batteries (NEW FOR BEST RESULTS)



* Items 5 and 6 are not included in your weemote package

STEP 3

REMOVING THE BATTERY COVER AND SETUP COVER

You must remove the setup cover in order to gain access to the weemote® program buttons.


Refer to the diagrams on the next page, figures A-D. Note that the screws are designed to remain on the covers so they don't get lost. Take care not to over tighten the screws when you put the covers back on.

NOTE: You cannot setup the weemote® until the setup cover is removed.

Need help? Go to www.weemote.com 4


STEP 3

CONTINUED



Removing the battery door Fig. A

Removing the setup cover Fig. B



Pull down to remove setup cover Fig. C

Weemote® setup buttons Fig. D



Need help? Go to www.weemote.com

5

STEP 4

WRITE DOWN YOUR CHILD'S FAVORITE CHANNELS

You do not need to setup all five.

1	_____	4	_____
2	_____	★	_____
3	_____		_____

The weemote® 2 can support up to 10 channels in the following manner. Channel 6 can be programmed to replace the MUTE button (small square Gray button) and channels 7-10 can be programmed but will only be available from the channel up/down button. Please refer to the reference guide for adding these additional channels.

APPLICATION FOR EASIER MOVIE VIEWING WITH THE WEEMOTE®

In this application, you could program the normally used MUTE button to go to either channel 3 or 4, depending on which channel you use to output your VCR signal. Now the child can pop the tape into the VCR, hit the play button and then press the weemote's square gray button to ensure that the TV will display the movie from the VCR deck. *To do this, please see the reference guide.*

Need help? Go to www.weemote.com

6

HINT - ENTERING CHANNELS


Before we begin to program in the channels, here is a quick overview on the 100, 10 and 1 buttons. These buttons allow you to program in the channels and code/s you will need to setup the weemote® 2. You must remove the setup cover in order to access these buttons.

Depending on which number you need, you simply break down that number by 100's, 10's and 1's. For example, channel 294 would be entered by pressing the 100 button twice (100 X 2), the 10 button nine times (10 X 9) and the 1 button four times (1 X 4). See diagram below.

And don't worry about zeros - the weemote® will add them in later. For example, if you need to enter channel 07 or 007 to get channel 7, just enter the number 7 (1 button seven times) and the weemote® will handle sending channel 07 or 007.

Example: To Enter Channel 294

PRESS - # TIMES



$$200 + 90 + 4 = 294$$

NOTE: You must program at least one favorite channel in order for the weemote® to work!

STEP 5

PROGRAM YOUR FAVORITE CHANNELS

1. Press and hold the "FAV" button for about three seconds until the LED light begins to flash.

2. Press the favorite channel button you wish to program - in this example we are using the (Green) Button Number "1" to program in channel 127.

3. Press the following combination of the 100, 10 and 1 buttons.

A. Press the "100" button X 1 time = 100

B. Press the "10" button X 2 times = 20

C. Press the "1" button X 7 times = 7

6. Press the Favorite Channel (Green) Button Number "1" again to complete the sequence. DO NOT PRESS THE FAV BUTTON. Please check the LED - it should flash three times and then go out to confirm that the channel has been programmed. If it does not, try again.

To setup favorite channels 2-5, simply use the steps above except that for Steps 2 and 6, you would substitute the Green Number 1 button for the other favorite channel button (2,3,4 or 5) you wish to program.

For programming channels 6-10, please refer to the reference guide.

STEP 6

SETTING YOUR TV OR TV/VCR CODE

1. Turn your TV on.
2. Please refer to the TV or TV/VCR CODES listed in the Reference Guide. **NOTE: TV AND TV/VCR CODES ARE LISTED SEPERATELY.** If you cannot find your brand TV or TV/VCR listed here, then please refer to the Reference Guide to search for your code.
3. Locate the first code for your TV or TV/VCR. For this example, we will use the code 109 which is the first listed for a SONY brand TV.
4. Press and hold the "TV" button for about three seconds until the LED light begins to flash.
5. Enter the Code number. In our example, we are using the SONY code number 109.

Press the "100" button 1 time = 100

Press the "1" button 9 times = 9

You do not use the "10" button in this case.

6. Press the "TV" button again to set the code. The LED should flash three times and then turn off to confirm that the code was entered.

Need help? Go to www.weemote.com

9

STEP 6

CONTINUED

7. Press the RED power button to see if the TV turns off. If it does not, then go back to the beginning of Step 6, using the next code number listed for your manufacturer. If you have run through all the possible codes and still cannot get the TV to power off, then please refer to the Reference Guide on how to search for your code.

STEP 7

HOW DO YOU USE YOUR EXISTING TV REMOTE CONTROL?

1. DO YOU USE THE ENTER KEY TO CHANGE CHANNELS?

YES: Please go to Page 15 to set the Enter Option, then continue to Step 8.

NO: Go on to question 2 below

2. WHEN YOU CHANGE CHANNELS, DO YOU USE ALL THREE DIGITS REGARDLESS OF THE CHANNEL NUMBER, I.E. CHANNEL 7 IS ENTERED ON YOUR REMOTE AS "007"?

YES: Please go to Page 15 to set the 3-Digit Option, then continue to Step 8.

NO: Go on to Step 8.

Need help? Go to www.weemote.com

10

STEP 8

TEST THE TV CODE

1. Make sure your TV is turned off.
2. Point the weemote® at your TV and press the Power (red) button. The TV should go on. Now, check the volume up/down button as well as the channel up/down button. If all these functions work, then you have the right code for your TV.

If any of the functions above do not work, then you will need to try another TV code. Go back and repeat Step 6.

NOTE: When you are finished testing and you are using a Set-Top box with your system, then you will need to set the TV back to the correct channel or video input (see Step 12).

STEP 9

LAST STEP FOR TV ONLY USERS!

1. Write the TV code down on the battery sticker located behind the battery door.
2. **If you are also using a Set-Top box, then you will need to proceed directly to STEP 10.**
3. Go ahead and reattach the Setup area cover and battery cover. **DO NOT OVERTIGHTEN THE SCREWS!!!**

Need help? Go to www.weemote.com 11

STEP 10

SETTING YOUR SET-TOP CODE

1. Turn on your Cable Box, Satellite Receiver or Personal Video Recorder.

Please note that TiVo and Replay (PVR) units are considered Set-Top devices to the weemote®. If you also have a Set-Top box with these units, you only need to program in the TiVo or Replay code as your STB setting.

2. Please refer to the CABLE, SATELLITE OR PERSONAL VIDEO RECORDER CODES listed in the Reference Guide. **NOTE: CABLE, SATELLITE AND PVR CODES ARE LISTED SEPERATELY.** If you cannot find your brand listed there, then please refer to the Reference Guide to search for your code.

3. Locate the first code for your brand Set-Top device.

4. Press and hold the "STB" button for about three seconds until the LED light begins to flash.

5. Enter the Set-Top Code number. In our example, we are using the Scientific Atlanta code number 003.

6. Press the "1" button 3 times = 3
In this example, there is no need to use the "100" and "10" buttons as the channel number is below 10.

7. Press the "STB" button again to set the code. The LED should flash three times and then turn off to confirm that the code was entered.

Need help? Go to www.weemote.com 12

STEP 10 CONTINUED

8. Press the RED power button to see if the Set-Top box turns off (***See Note Below**). If it does not, then go back to the beginning of Step 10, using the next code number listed for your manufacturer. If you have run through all the possible codes and still cannot get the Set-Top box to power off, then please refer to the Reference Guide on how to search for your code.

* Some codes may operate channel changing but not power. If you leave your Set-Top normally on, then you can use one of these codes. In this case, for each code tested, try to see if you can change channels by pressing the channel up/down button (long blue button) By using one of these codes, the weemote® will not power the Set-Top box on/off.

STEP 11 HOW DO YOU USE YOUR EXISTING SET-TOP REMOTE CONTROL?

1. DO YOU USE THE ENTER KEY TO CHANGE CHANNELS?

YES: Please go to Page 15 to set the Enter Option, then continue to Step 12.

NO: Go on to question 2 below

2. WHEN YOU CHANGE CHANNELS, DO YOU USE ALL THREE DIGITS REGARDLESS OF THE CHANNEL NUMBER, I.E. CHANNEL 7 IS ENTERED ON YOUR REMOTE AS "007"?

YES: Please go to Page 15 to set the 3-Digit Option, then continue to Step 12.

NO: Go on to Step 12.

Need help? Go to www.weemote.com 13

STEP 12 TEST THE SET-TOP CODE

IMPORTANT NOTE: If your Set-Top box is set to use Channel 2,4,5 on your TV or your TV is cabled using direct video connections (RCA Jacks or S-Video), then please go to Page 16 to set the Channels/Direct Video option, then come back to this Step.

1. Make sure your TV and Set-Top box is turned off.

2. Point the Weemote® at your Set-Top box and press the Power (red) button. The Set-Top box should go on as well as the TV. Now, check the volume up/down button as well as the channel up/down button. If all these functions work, then you have the right code for your Set-Top box.

If any of the functions above do not work, then you will need to try another Set-Top code. Go back and repeat Step 10.

STEP 13 FINISHING UP

1. Write the Set-Top code down on the battery sticker located behind the battery door.

2. Go ahead and reattach the Setup area cover and battery cover. **DO NOT OVERTIGHTEN THE SCREWS!!!**

Need help? Go to www.weemote.com 14

SETTING THE ENTER OPTION

A small number of TV's and SET-TOP boxes require that the ENTER key be used when changing channels. The best way to tell whether you need to use this option is to use your existing remote. Point your existing remote at your TV or SET-TOP box, and then change a few channels. Now try using the Enter button on your remote. Did the channels change faster? If yes, proceed with this setup, otherwise you do not need to use this option.

STEP 1: Press and hold the "TV" or "STB" button, depending on which unit needs the enter option. Hint: If you are using a SET-TOP box, then press the STB button. After about 3 seconds, the LED light will flash.

STEP 2: Press the "FAV" button once.

STEP 3: Press the NUMBER "1" button located in the setup area next to the 100 and 10 buttons. The LED light flashes three times and then goes out to confirm that the option has been set.

STEP 4: Continue on to Step 8 (TV) or Step 12 (Set-Top) to complete your setup.

Note: If you go back and change the TV or STB code, the ENTER option will be cleared.

SETTING THE 3-DIGIT OPTION

The latest digital TV and SET-TOP boxes support hundreds of channels. These units typically require that you enter three digits, regardless of the channel number. For instance, channel 7 cannot be entered as simply 7, but rather 007.

The best way to tell whether you need to use this option is to use your existing remote. Point your existing remote at your TV or SET-TOP box, and then select channel 7. Did you need to enter in 007 in order for the channel to change? If so, then complete this section.

STEP 1: Press and hold the "TV" or "STB" button, depending on which device requires this option, for about 3 seconds, until the LED light flashes.

STEP 2: Press the "FAV" button once.

STEP 3: Press the "100" button once. The LED light flashes three times and then goes out to confirm that the option has been set.

STEP 4: Continue on to Step 8 (TV) or Step 12 (Set-Top) to complete your setup.

NOTE: If you go back and change the TV or STB code, the 3-DIGIT option will be cleared.

CHANNELS/DIRECT VIDEO OPTION

In most cases, your Set-Top box is set to run with your Television tuner set to channel 3. In some cases, your Set-Top box tuner may be set to run with your Television tuner set to channel 2, 4, 5 or your Set-Top may be cabled directly to your TV's video port. To set this option, please do the following.

STEP 1: Press and hold the "TV" button for about three seconds until the LED light flashes.

STEP 2: Press the "CHANNEL UP" button (top of long blue button) once.

STEP 3: Press the Favorite Channel button that corresponds to your setup (see table below). The LED light flashes three times and then goes out to confirm that the option has been set.

Set-Top Channel/Direct Video to TV Table

TV set to Video Port, Press Channel #1 (Green)

TV set to channel 2, Press Channel #2 (Blue)

TV set to channel 3, Press Channel #3 (Orange)

TV set to channel 4, Press Channel #4 (Purple)

TV set to channel 5, Press Channel #5 (Yellow)

NOTE: To change this option again, simply repeat the steps above except that in STEP 3, press the desired button (see table above).

TROUBLESHOOTING

Please check the support section on our web site if you do not see your problem listed below.

1. The LED does not light or flash?

Check to make sure you have installed the batteries properly. Check to make sure that the batteries are not dead or too weak to operate the weemote®.

2. The weemote® powers on my TV or SET-TOP but does not change channels?

The weemote® must have at least one channel programmed in order for channel changing to work. Press the channel buttons you programmed. If the LED does not light up brightly, i.e. the light is dim, then the channels have not been entered or programmed properly. Please go back to Step 5 and repeat entering your channels.

If your setup is TV only, make sure you did not program in a set-top code by mistake. Try clearing the STB code by referring to the reference guide.

Check to make sure you have set the proper code in the weemote®. Sometimes a code will only partially work. Fully test each code as described in this manual.

3. I see the correct channel digits on my TV but the channel does not change?

Make sure you programmed in the ENTER option or 3-Digit option, depending on what your equipment needs. Some TV's or Set-Top boxes will not change channels until either 3 complete digits or an ENTER command has been sent from the weemote®.

4. When changing channels, the channel numbers that are sent to the TV from the weemote® are not the same as what I programmed?

Check to make sure you have set the correct code in the weemote®. This happens frequently with Sony codes. The weemote is designed to output exactly the

Need help? Go to www.weemote.com 17

TROUBLESHOOTING

channel number you program in when pressing the channel buttons in normal operation. Keep trying other codes.

5. The channel digits on my TV display show always show either the first or last digit I programmed in. For example, channel 57 shows up as channel 5 or 7?

It sounds like you need to make some speed adjustments in the weemote®. Please contact us for specific instructions on how to do this.

6. Whenever I turn on the Set-Top box, the TV turns on, then back off.

Check to see if your TV is plugged into your set-top box. If so, plug it directly into an AC outlet.

7. The channel up/down button only goes to the channels I programmed in the weemote®?

This is normal since the weemote® is designed to limit channel access.

8. I notice that sometimes the weemote® seems to get confused. Sometimes, the programmed channels get knocked out of alignment when the child is pressing the buttons too quickly?

There are two possible problems here. The first is to check and make sure whether you need the ENTER or 3-Digit option. Some TV's and Set-Tops will delay until they change channels if they do not see 3-Digits or an ENTER command. Without this option set, channel changing will be unreliable.

Depending on your TV or Set-Top, the weemote® may be sending the channel changing information too slowly. Please contact us if you have this problem.

9. I am confused with exactly what I have setup in the weemote® at this point. What should I do?

Your best bet is to reset the weemote® and start over. Refer to the reference guide.

Need help? Go to www.weemote.com 18

CARE AND MAINTENANCE

1. Keep the weemote® dry. If it gets wet, wipe it dry immediately. Liquids may contain minerals that can corrode the case and electronics.
2. Use and store the weemote® only in normal temperature environments. Temperature extremes can shorten the life of the electronics, warp the plastic body and cause the batteries to leak.
3. Keep the weemote® away from excessive dust, dirt or sand. Exposure to these elements can cause the keypad to work erratically or fail altogether.
4. Handle the weemote® with care. Dropping the unit frequently can cause the case to crack as well as the internal electronics to malfunction.
5. Use only fresh batteries and take them out if you do not plan to use the weemote® for long periods of time. Batteries that leak can cause extensive damage to the Weemote®.
6. Wipe the weemote® with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents as they may cause permanent damage to the weemote's finish.

Modifying or tampering with the weemote's internal components can cause malfunction and may invalidate your warranty. If your weemote® is not performing properly, please complete a trouble report at our Customer Support page on our website.

LIMITED WARRANTY

Fobis Technologies Inc. ("FOBIS") warrants, to the original purchaser only, that this product will be free from defects in materials and workmanship, under normal use, for ninety (90) days from the date of original purchase.

This warranty does not cover damage or failures caused by products or services not supplied by FOBIS, or which result from accident, misuse, abuse, neglect, mishandling, misapplication, faulty installation, setup adjustment, improper maintenance, alteration, maladjustment of consumer controls, modifications, commercial use, or that is attributable to acts of GOD.

There are no express warranties except as listed above. FOBIS SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF WARRANTY. ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE WARRANTY PERIOD SET FORTH ABOVE. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

To obtain warranty service for a defective product during the warranty period, please return the product, preferably in the original package, along with your purchase receipt, to the company of your original purchase. A note detailing the complaint would be helpful. The store, at its option, will replace or repair this product if found to be defective.

Fobis Technologies Inc.
(305) 253-8387
Email: support@fobis.com